

06- COMMUNITY AND KITCHEN LINE

D.D.L.3003 LIME SCALE REMOVING DETERGENT FOR DISHWASHING & WASHING-MACHINE

CHARACTERISTICS : this product has been formulated to remove lime scale deposits and ferruginous encrustations from dishwashers, washing-machine and equipment in general.

DILUTION & USE : prepare a solution containing 2% to 10% (200 ml - 1 l product in 10 l water) product according to the thickness of the lime scale and ferruginous layers to remove.
- Let the machine work for 15 – 20 minutes at a temperature of 40° - 50°.
- Discharge the solution and rinse abundantly.

USE :
1) apply the solution by brush or spray or by dripping.
The contact time is very important in order to favour the chemical attack of the layers to remove;
2) rinse abundantly with water .

Labelling according to Regulation (EC) No 1272/2008:

Hazard statement **Danger** Causes severe skin burns and eye damage.

Code(s):



Supplemental Hazard statement Code(s): not applicable

Precautionary statements: Do not breathe vapours.
Wear protective gloves/protective clothing/eye protection/face protection.
IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.
IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower].
IF INHALED: Remove person to fresh air and keep comfortable for breathing.
IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
Immediately call a POISON CENTER/doctor.
Dispose of the product/container in accordance with existing regulations.

Contains: phosphoric acid

UFI: NKT2-60K0-N003-D7G4

Safety data sheet available on request for professional users