

07- LINEA ECOSPOT®

DECALC/LC

LIME SCALE REMOVING DETERGENT FOR DISHWASHING & WASHING-MACHINE

CHARACTERISTICS : this product has been formulated to remove lime scale deposits and ferruginous encrustations from dishwashers, washing-machine and equipment in general.

DILUTION & USE : prepare a solution containing 3% to 15% (300 ml – 1,5 l product in 10 l water) product according to the thickness of the lime scale and ferruginous layers to remove.
 - Let the machine work for 15 – 20 minutes at a temperature of 40° - 50°.
 - Discharge the solution and rinse abundantly.

USE :

- 1) apply the solution by brush or spray or by dripping.
The contact time is very important in order to favour the chemical attack of the layers to remove;
- 2) rinse abundantly with water .

Labelling according to Regulation (EC) No 1272/2008:

Hazard statement **Warning** Causes skin irritation.
Code(s): Causes serious eye irritation.



Supplemental Hazard statement Code(s): not applicable

Precautionary statements: Wash with water thoroughly after handling.
 Wear protective gloves/protective clothing/eye protection/face protection.
 IF ON SKIN: Wash with plenty of water.
 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
 If skin irritation occurs: Get medical advice/attention.
 If eye irritation persists: Get medical advice/attention.

Contains: phosphoric acid.

UFI: CWA3-C0QE-U004-236D

Safety data sheet available on request for professional users