ECOCHEM srl

Via del Lavoro, 10 24058 Romano di L.dia (Bg) ITALY Tel./Phone +39 0363 901933 Fax +39 0363 902664



www.ecochem.it E-mail: ecochem@ecochem.it Partita IVA 01901410165 Trib. di BG Soc. n°35378 R.E.A. n° 246240

Sistemi di detergenza in "perfetta forma" Detergents & Cleaning Systems in "perfect form"

11 - AUTOMOTIVE LINE

ALL BRIGHT

CONCENTRATED PRE-WASHING & WASHING DETERGENT

CONCENTRATE

CHARACTERISTIC PRE-WASHING / WASHING FOAMY DETERGENT. S: High performances on any kind of soil, it solves orga

High performances on any kind of soil, it solves organic and inorganic greases and soil. It doesn't leave any residuals. Suited in presence for hard water too. Excellent for washing/pre-washing of all vehicles.

DILUITION SHAKE THE PRODUCT BEFORE USE !

& USE :

By SPRAY GUN or a LOW PRESSURE MACHINE - Suggested solution: from 1,5% till 2% (150 ml - 200 ml product to 10 l water).

Spray the surface to clean, let the product work a little bit and rinse.

In automatic washing systems, dosing pump equipped, we suggest to use pure product and program the pomp directly, putting the inlet of the pure product on 15 g -20g /per vehicle, in compliance with the used system and its specific washing and working conditions (ex.: speediness of the chain, type of washing plant, temperature, etc.).

IMPORTANT!

<u>This is an high alkalinity product, that's why, during warm seasons we suggest to work</u> <u>on cold surfaces (let your surface become cold!) and lower concentration.</u> <u>AVOID to keep in touch long time with aluminium and its alloys.</u>

Labelling according to Regulation (EC) No 1272/2008:

Hazard statement Danger Causes severe skin burns and eye damage.



Precautionar Do not breathe vapours.

 y statements: Wash with water thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/doctor.Store locked up. Dispose of the product/container in accordance with existing regulations.
Contains: 1-Hydroxyethane diphosphonic acid sodium salt solution, sodium hydroxide, Anionic surfactants, mixture of non-ionic surfactants and amphoteric surfactants, non-ionic surfactants

Contains>= 5% < 15% anionic surfactants,< 5% mixture of cationic surfactants, non-ionic and
amphoteric, non-ionic surfactants, EDTA and salts thereof

UFI: CNS2-M0YN-800N-3G2E

Safety data sheet available on request for professional users

Rel. 3.1 on 02/13/2024 CODES : AU40204K0258283 – AU40204K0018779 - AU40204K0018780