

06- COMMUNITY AND KITCHEN LINE

DETERGENT FOR COFFEE MACHINES AND CUP CLEANING C.M.C.3008

DOSES AND USE :

CLEANING OF FILTERS AND FILTER HOLDERS

- 1) prepare a solution (2 tablespoons of product per litre of boiling hot water) in a plastic, stainless steel or glass container (DON'T USE IRON OR ALUMINIUM !);
- 2) put the filter and filter holders in the solution for 20 - 30 minutes (better still a whole night);
- 3) rinse well in plenty running water.

CLEANING OF CUPS, SAUCERS AND TEAPOTS

The product is particularly suitable for removing the stains from cups, saucers, teapots, etc., leaving them sparkling.

Dissolve 2 tablespoons of product per litre of boiling hot water and leave cups, saucers, etc. in this solution until it becomes cold; then rinse them in plenty runny water.

CLEANING THE UPPER FILTER

- 1) put 1 tablespoon of the product in the blind filter of each group;
- 2) open the delivery valve for about 30 seconds;
- 3) close the delivery valve;
- 4) repeats points 2 and 3 until the water discharged is perfectly clean;
- 5) rinse several times using a normal filter.

Labelling according to Regulation (EC) No 1272/2008:

Hazard statement **Danger**
Code(s):



Causes serious eye damage.
Harmful if inhaled.
May cause respiratory irritation.
May damage the unborn child. Suspected of damaging fertility.

Precautionary statements:

Obtain special instructions before use.
Avoid breathing vapours.
Wear protective gloves/protective clothing/eye protection/face protection.
IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
Call a POISON CENTER/doctor/if you feel unwell.
Store in a well-ventilated place. Keep container tightly closed.

Contains:

sodium metasilicate pentahydrate, Alcohol ethoxylate, perboric acid (HBO(O₂)), sodium salt, tetrahydrate [containing < 0,1 % (w/w) of particles with an aerodynamic diameter of below 50 micron]

Contains
(Reg.EC 648/2004):

5% < 15% non-ionic surfactants
< 5% anionic surfactants

PROFESSIONAL USE ONLY

Rel. 1.0 on 09/22/2015

CODES : 0830080K0013148